



Information booklet

for


machine GL4



GL4 with *HERBICIDE*




Swing arm





Power transmission elements

Type I
GL4-110-160




Type II
GL4-180-240






Mainframe blades & swing arm blades



**Cutting hight adjustment
(4-7cm)**

Thread spinle for rear
roller adjustment

3 Positions for hight
adjustment in front



D

C

- B


B

- A




Types of ATTACHMENTS


REAR mounting




FRONT-mounting



FRONT-REAR-mounting



Rear mounting with
HYDRAULIC SIDE SHIFT



Rear mounting for
SPRAYING EQUIPMENT

